

342 AC Acid Cleaner Aluminum Brightening

ALTERNATE NAMES

Mineral Acid Cleaner, Aluminum Cleaner, Phosphoric Acid, Pre-Bright Dip Cleaner

DESCRIPTION

342 AC is a clear phosphoric acid-based liquid with an organic odor and a density of approximately 10.8 pounds per gallon. 342 AC is an environmentally friendly cleaner with low foam retention and free of NPE.

PHYSICAL COMPOSITION	
CHEMICAL NAME(S)	% BY WEIGHT
Phosphoric Acid, as H ₃ PO ₄	~ 43

SPECIFICATIONS			
	MIN	MAX	UNITS
Assay as H ₃ PO ₄	42.0	45.0	%
Specific Gravity at 60/60°F	1.28	1.30	-
Cloud Point	95	-	°F

PACKAGES 55-gallon drum, bulk

SHIPPING Refer to SDS

SAFETY, STORAGE & HANDLING Refer to SDS

APPLICATIONS & OPERATING GUIDELINES

Application – For the superior removal of ground-in buffing compounds and drawing oils left after extruding, drawing, stamping or rolling aluminum. 342 AC is designed as a second stage cleaner following a mild, non-etching alkaline cleaner, but it may be used as a single stage cleaner where the soil load is light.

Addition – 342 AC is designed to operate at 8-9% by volume diluted with water.

Operation – Recommended operating temperature is 120-160 °F, depending on the amount of cleaning action desired. An increase of 20 °F approximately doubles the amount of cleaning action. For uniform results, accurate temperature control is desirable. Suggested immersion time is 2 minutes.

The cleaner tank should be of such construction as to hold phosphoric acid at the operating temperature required. 316L Stainless Steel, rubber-lined steel or fiberglass is recommended.

342 AC Acid Cleaner Aluminum Brightening

CLEANER BATH ANALYSIS

Reagents Required:

1. Sodium Hydroxide Solution (NaOH), 0.5N
2. Indicator Solution (Bromophenol Blue): Dissolve 0.1 g Bromophenol Blue in 7.1 ml of 0.02N Sodium Hydroxide and dilute to 250 mL with distilled water.

Apparatus Required:

1. 250 mL Erlenmeyer flask
2. 10 mL burette
3. 10 mL pipette

Procedure:

1. Pipette 10 mL of the acid cleaner solution into the 250 mL Erlenmeyer flask.
2. Add about 40 mL of water and 2-3 drops of the indicator.
3. Titrate with the 0.5N Sodium Hydroxide (NaOH) to the end point (change from greenish yellow to the first distinct blue color or pH 4.5).

Calculation:

% cleaner (by volume) = mL of 0.5N NaOH x 0.92.

FOR FURTHER INFORMATION OR TECHNICAL ASSISTANCE

PCS Sales (USA), Inc. (a subsidiary of Nutrien Ltd.)

Suite 150, 500 Lake Cook Road
Deerfield, IL 60015
1 (800) 524-0132

Aurora Phosphate Operations

1530 Hwy 306 South
Aurora, NC 27806
1 (866) 208-0931

Refer to a Safety Data Sheet for more information

To the best of Nutrien's knowledge, the information contained herein is accurate and reliable as of the date compiled; however, Nutrien makes no representation, warranty or guarantee as to the information's accuracy, reliability, completeness or timeliness. It is the user's responsibility to determine the suitability and completeness of such information for the user's own uses or purposes. Nutrien does not accept any liability for any loss or damage that may occur from any use of this information.

Product is manufactured by the following subsidiary of Nutrien Ltd.:

PCS Sales (USA), Inc. · Suite 150, 500 Lake Cook Road · Deerfield, IL · 60015 · USA · (847) 849-4200 · 1-800-524-0132